


HDMI Over Ethernet is based on TCP/IP standard. It transmits your HD display with the high resolutions up to 120 metres away from your HDMI or DVI-D source by using one CAT5e/6 cable. With the advantage of TCP/IP standard, you can extend your HD video to multiple displays by using an Ethernet Switch.


- Following TCP/IP standard.
- Support HDMI1.3 protocol.
- HDCP1.1 & 1.2 protocol compliant
- Support point-to-point mode, one point-to-many mode and cascade connection mode.
- Support IR extender function allows IR remote control of Source devices from remote viewing location by sending IR commands received in the vicinity of the Display back to the Source devices.




Application 1



HDMI Transmitter



HDMI Receiver



5V/1A	Supply power for the Transmitter	5V/1A	Supply power for the Receiver
Reset	Hold down the key, the model will re-start	Reset	Hold down the key, the model will re-start
IR-out	Connect IR transmitter this Port	IR-in	Connect IR Receiver this Port
HDMI-in	Connect HDMI sink source to this Port	HDMI-out	Connect HDMI sink device to this Port

HDTV Resolutions	480p,576p,720p,1080p
Audio	Sample rate:32kHz,44.1kHz,48kHz
IR remote control	38kHz;NEC
HDMI	HDMI 1.3
HDCP	HDCP 1.2
Power adapter	Input : 100V-240V(50-60Hz) Output:5V/1A
Power consumption	HDMI Sender:3W HDMI receiver:3W
Size(L-W-H)	92x79x20mm
Weight	240g x 2
Operating Temperature/Humidity	0 -70 /10%-80%RH(no condensation)
Storage Temperature/Humidity	-10 -80 /5%-90%RH(no condensation)

Connection and operation

- 1) Connect the HDMI source (such as DVD, PS3, STB) to the HDMI IN of Sender.
- 2) Connect the IR sender to the Sender IR OUT Port, and Be Directed at HDMI video source's IR receiver.
- 3) Connect the HDMI out of Receiver to HDTV display.
- 4) Connect the IR receiver to the Receiver IR IN Port.
- 5) Use one Cat5e/6 cable up to 120m to connect the Sender and Receiver.
- 6) Plug two pieces of 5V power supply into the Sender and Receiver.
- 7) Power on the HDTV display and HDMI source.

PACKAGE CONTENTS

Before attempting to use this unit, please check the packaging and make sure the following items are contained in the shipping carton:

- 1) Main unit No. 1 Sender , Main unit No. 2 Receiver
- 2) Two pieces of 5V DC Power Supply.
- 3) one piece of IR transmitter and one piece of IR receiver
- 4) User's Manual